

FIG. 1





FIG. 2






CONFIGURATION MESSAGE



<u>500</u>



TOPOLOGY CHANGE NOTIFICATION MESSAGE

FIG. 5



<u>600</u>


608~ 610~ PORT 2 RG ~ 608A 602 612A 616A RG 5 RG 7 8 6 612^ 616~ 618

FIG. 6

4



<u>700</u>



PORT STATE TABLE PRIOR ART

FIG. 7








FIG. 8

--




900

	STATE	ROLE	
	FWD	ROOT PORT	> -710
	FWD	DESIGNATED PORT	> -712
	BLK	BLOCKED PORT	> -714
902A	BLK	ROOT INCONSISTENT PORT	902

PORT STATE TABLE

FIG. 9





STATE DIAGRAM FOR STD FOR THE ROOT GUARD ON A PORT

FIG. 10

_



10/10

11,000




FIG. 11